



Contact & Postal Info:

Tel: +27 11 903 9204 Fax: +27 12 212 2341 Web: www.fiberroofing.com E-mail: info@fiberroofing.com

P.O.Box 639, Alberton, 1450

FACTORY ADDRESS: INDUSTRIAL SITE - R59, KLIPRIVER, 1871, GAUTENG, SOUTH AFRICA

FIBERREED: FITTED ON TO EXTERIOR SHUTTER PLY

(The answer to renew old thatch roofs or clad a new roof)

Fiber Thatch Tiles can be fitted to any type of sub roof. The photos show an application to Marine Ply or Exterior Shutter Ply.

The roof ply must be waterproofed. Any available waterproof material can be used. The Fiber Tiles are then stapled to the Ply board using $25mm(1") \times 4mm(1/8")$ galvanized staples. The spacing should be 230mm.

On a new construction for the interior finish various ceiling finishes can be used. Possibilities are Cape Reed, Alang Alang, Thatch Grass or Palm. The natural Marine-ply or Exterior Shutter ply as well as our Cape Reed Ceiling Boards also gives a beautiful finish.

The ply board and waterproofing provide excellent insulation. No additional insulation is required. For more information visit www.fiberthatchguide.com

The photos illustrate the various steps.









Natural Thatch roofs.

From left to right:

- 1. Timber strips or battens are screwed down on top of the thatch.
- 2. Marine or Roof Ply is screwed down onto the strips.
- 3. A waterproofing membrane is laid down onto the Marine or Roof Ply.
- 4. Fiber Tiles are stapled on.

A before and after natural thatched roof done as described above.





Fregate Resort, Seychelles.